D t l · ·		1-7.	Safety information	
1	Before driving		Correct driving posture	59
			SRS airbags	61
1-1.	Key information		Passenger occupant	
	Keys 20		classification system	72
			Child restraint systems	76
1-2.	Opening, closing and locking the doors		Installing child restraints	80
	Wireless remote control	2	When driving	
	Rear hatch29	2-1.	Driving procedures	
1-3.	Adjustable components		Driving the vehicle	88
	(seats, mirrors,		Ignition switch	98
	steering wheel)		ASG (Automated	
	Seats		Sequential Gearbox)	
	Seat belts		Turn signal lever	
	Steering wheel		Parking brake	
	Anti-glare inside rear		Horn	115
	view mirror 42	0.0		
	Outside rear view mirrors 43	2-2.	Instrument cluster	
			Gauges and meters	116
1-4.	Opening and closing		Indicators and warning	101
	the windows		lights	
	Power windows 46		Using the menu	124
1-5.	Refueling	2-3.	Operating the lights and	
	Opening the fuel tank cap 49		windshield wipers	
	Opening the fact tank cap +7		Headlight switch	158
1-6.	Theft deterrent system		Windshield wipers and	
	Engine immobilizer system 53		washer	160
	Alarm55			
	, I I			

/	/		
/	/		
/	′		

Z- 4 .	Using other driving systems	J-J.	Using the interior lights	
	Rear view monitor system 163		Interior lights list20)7
	Driving assist systems 166			
	Active rear wing 171	3-4.	Using the storage features	
	Launch control 174		List of storage features	
			• Glove box	
2-5.	Driving information		• Door pockets	12
	Cargo and luggage 176		Other interior features	
	Vehicle load limits	J -J.		12
			Sun visors	
	Trailer towing 182		Floor mats	
	Dinghy towing 183			IJ
			Luggage compartment features	I8
3	nterior features		Safety Connect	
3.1	Using the air conditioning	4	Maintenance and care	_
J 1.	system and defogger	4	Tamenance and care	_
J	system and defogger Automatic air conditioning		Maintenance and care	
5	system and defogger Automatic air conditioning system (with navigation system)		Maintenance and care Cleaning and protecting	:8
J	System and defogger Automatic air conditioning system (with navigation system)		Maintenance and care Cleaning and protecting the vehicle exterior	:8
J	System and defogger Automatic air conditioning System (with Navigation system)		Maintenance and care Cleaning and protecting	
J	system and defogger Automatic air conditioning system (with navigation system)	4-1.	Maintenance and care Cleaning and protecting the vehicle exterior	
J	System and defogger Automatic air conditioning System (with Navigation system)	4-1.	Maintenance and care Cleaning and protecting the vehicle exterior	35
	system and defogger Automatic air conditioning system (with navigation system)	4-1.	Maintenance and care Cleaning and protecting the vehicle exterior	35
	system and defogger Automatic air conditioning system (with navigation system)	4-1.	Maintenance and care Cleaning and protecting the vehicle exterior	35
	System and defogger Automatic air conditioning system (with navigation system)	4-1.	Maintenance and care Cleaning and protecting the vehicle exterior	35
	System and defogger Automatic air conditioning system (with navigation system)	4-1.	Maintenance and care Cleaning and protecting the vehicle exterior	35 10 12

4-3. Do-it-yourself maintenance

Do-it-yourself service	
precautions	247
Hood	250
Positioning a floor jack	253
Engine compartment	
Adding washer fluid	264
Battery	265
Tires	270
Tire inflation pressure	277
Wheels	281
Air conditioning filter	283
Wireless remote control battery	285
Checking and replacing fuses	287
Light bulbs	299

5 When trouble arises

5-1 Essential information Emergency flashers...... 302 If your vehicle needs to be towed 303 If you think something is wrong.......308 Fuel pump shut off system 309 5-2. Steps to take in an emergency If a warning light turns on or a warning buzzer sounds... 312 If a warning message is displayed...... 322 If the engine will not start 343 If you lose your keys/ wireless remote control transmitter.......344 If the parking brake cannot be released 345 If the vehicle battery is discharged 348 If your vehicle overheats............ 351 If the vehicle becomes If your vehicle has to be stopped in an

6-1.	Specifications
	Maintenance data (fuel, oil level, etc.) 358
	Fuel information
	Tire information
6-2.	Customization
	Customizable features 383
6-3.	Initialization
	Items to initialize
7	For owners
	Reporting safety defects for U.S. owners
	Seat belt instructions for Canadian owners (in French)
	SRS airbag instructions for Canadian owners
	(in French)

Vehicle specifications

Abbreviation list	400
Alphabetical index	402
What to do if	415

Index